



## INWARD TRANSFER 200 RIGHT

Code: 430070/0

[Link to the product →](#)



### Technical data/items supplied

- Inward transfer, left Art. no. **430071/0**
- Pneumatically actuated
- Carrier profile 45 x 90
- WT-guide 2 parts, PE
- Cover PE
- Friction wheel with drive roller
- 2 Pneumatic cylinders
- 4 beams
- Fastening material

### Applications

- Return WT's from secondary sections into the base circuit
- Separation of work procedures from machine cycle
- Inserting further processing stations
- Forming storage units
- When the inlet is active, the WT is deflected from the secondary section into the base circuit
- The orientation of the WT is not changed. Status request of transfer with sensor
- Suitable for track width 200

### Assembly

- Mount friction wheel on pulley (in conveyor direction, at the longer conveyor side)
- Install pneumatic cylinder
- Install the guide curve
- Screw on cover
- Connect and align the transverse transport with beams
- Connect pneumatic cylinder to compressed air supply